

Table Top Vacuum Sealer Oil Kits

Machine & Pump		Oil Kit = Every 6 months		Oil & Filter Kit = Every 18 months		Oil, Filter & Conditioning Kit = Every 36 months	
Model	Pump	15 Wt Oil	Kit #	Filter	Kit #	Oil	Kit #
MVS 26X	7 m ³ /h	7 oz	KR070000	1	KR071510	7 oz	KR07151C
MVS 26XII	7 m ³ /h	7 oz	KR070000	1	KR071510	7 oz	KR07151C
MVS 31X	7 m ³ /h	7 oz	KR070000	1	KR071510	7 oz	KR07151C
MVS 31XP	7 m ³ /h	7 oz	KR070000	1	KR071510	7 oz	KR07151C
MVS 35X	12 m ³ /h	11 oz	KR110000	1	KR111540	11 oz	KR11154C
MVS 35XP	12 m ³ /h	11 oz	KR110000	1	KR111540	11 oz	KR11154C
MVS 41X	24 m ³ /h	14 oz	KR140000	1	KR141540	14 oz	KR14154C
MVS 41XP	24 m ³ /h	14 oz	KR140000	1	KR141540	14 oz	KR14154C
MVS 45X	24 m ³ /h	14 oz	KR140000	1	KR141540	14 oz	KR14154C
MVS 45XII	24 m ³ /h	14 oz	KR140000	1	KR141540	14 oz	KR14154C
MVS 45XP	24 m ³ /h	14 oz	KR140000	1	KR141540	14 oz	KR14154C
MVS 45XPII	24 m ³ /h	14 oz	KR140000	1	KR141540	14 oz	KR14154C

Oil Kit = Consist of oil, wrenches and instruction. **Oil & Filter Kit** = Consist of oil, exhaust filter, wrenches and instruction.

Oil, Filter & Condition Kit = Consist of oil, filter, conditioning oil, wrenches and instruction.