

Tips

Never lay a vacuum chamber machine on its side.

- Pump oil can bleed into the filter, sensor and chamber creating numerous issues.

Power the machine directly into a wall receptacle.

- Extension cords can create a low voltage situation making the pump motor overheat.

Change the oil and filter frequently.

- Food products vacuumed at a high level release moisture in the chamber contaminating the oil.

Maintain a low sealing time.

- A seal time of 1.5 seconds is usually sufficient for most bags and will extend the life of the Teflon tape.

Always use a liquid tray when sealing liquids.

- A liquid tray holds bags at a 40 degree angle preventing spillage into the chamber and sealing system.